


BUTLER EQUIPMENT

FPF In-and-Out Tiller



<u>FPF MODEL</u>	<u>WEIGHT (LBS)</u>	<u>MIN. ROW WIDTH (H)</u>	<u>MINIMUM</u>	<u>MAXIMUM</u>	<u>WITH HEAD INCLINED</u>	
			<u>EXTENSION (L)</u>	<u>EXTENSION (M)</u>	<u>MIN. EX. (L1)</u>	<u>MAX. EX. (M1)</u>
FPF 50-MF	880	98	62	76	62	76
FPF 60-MF	902	101	66	80	70	84
FPF 55	946	99	66	80	68	82
FPF 67	968	103	70	84	74	88
FPF 80	990	109	76	90	76	94
FPF 92	1012	115	82	96	86	99
FPF 104	1034	121	88	101	92	105
FPF 116	1056	129	94	117	98	119

(ALL MEASUREMENTS IN INCHES FROM MID-POINT OF TRACTOR)